

INSTRUCTIONS FOR LOADING DISPENSER



1 Remove the first few labels on the roll.



2 Feed liner under the first bar and over the second bar.



3 Feed liner between second bar and coiled third bar.



4 Pull on liner until label is released.